

INSTRUCTIONS FOR TRIPLE STAGE FILTRATION



Insert Baffle into the Instant Polish Envelope



Fold flap over towards the hole, secure Envelope flap with clamp



Tighten the knurled Nut on the stand pipe to the suction fitting protruding through the Envelope



Place Instant Polish Envelope Assembly into the tub keeping the stand pipe towards front of tub



Place Sludge Pan in tub, Overflow holes towards the rear



Place the Sludge Screen on the Sludge Pan, handles toward side of pan



Place Breeding Strainer on top of Sludge Screen



Install Splash Guard cover with stand pipe protruding through opening



Connect hose to stand pipe



Slide Tub between docking guides under fryer



Align Male connect into Quick Connect and secure hose



Make sure there is a tight connection