

Switches, Micro



18185- Micro Switch, Pump

Used on all Fryers

Dimensions: (3 prong)

2 1/2" Arm x 2" Body x 1/2" Body Width

White button under arm




18A332- Micro Switch W/Leads

Used on all 2008+ Basic Models With No Distribution Box,
No Computer (Only Trakstat Thermostats)

Dimensions: (0 Prong)

2" Arm x 1 1/2" Body x 5/8" Body Width, w/ 3 Wires- Red, Blue, Black

Red Button under arm



18A311- Switch, Micro DPDT UBR SC PNP

Used on Self Cleaning Fryers

Dimensions: (6 Prong)

2 1/2" Arm x 1 3/4" Body x 1" Body Width

Black Button under arm

