

RESETTING OF PUMP MOTOR



TO RESET PUMP MOTOR.

**PUSH RED BUTTON ON
MOTOR INWARD.**

*** NOTE***

**(motor needs to be cooled down
to be able to get it to rest)
(you should be able to hear / feel
a click when it resets)**

**INSURE PROPER CLEANING MAINTENANCE
IS BEING PERFORMED NIGHTLY
CALL 800-525-8130 FOR HELPFUL INSTRUCTION**