


Various Controllers



Hinged at bottom

Bottom panel
w/ silver knob

**Older Model
U25/U21 Controllers
Prior to 2006**
Door hinged at bottom,
must pull forward to open

**Cadet Model
U11 Controller**
Must pull whole
panel to open

**New Model
U25 Controller**
After 2006
Bottom panel opens
w/ silver knob