


GREASE CUPS



**ARE YOUR EXHAUST HOOD GREASE
FILTER CUPS IN PLACE &
DOING THERE JOB ? ?**

OR

**ARE THEY MISSING &
GREASE IS DRIPPING INTO
THE BACK OF YOUR FRYER.**



**THIS MAY SHORTEN THE
LIFE OF YOUR FRYER**